



Rev: January 26, 2024

Installation Instructions:

Step 1: Roll out product with grey printed side facing up, and black chemically treated slip resistant surface facing down. The top GripSpot® embossed raised fiber surface provides liquid absorption as well as an enhanced slip resistant walking surface.

Note: Printing ink from top surface may transfer to flooring or carpet if material is used upside down.

Step 2: Lift product away from the floor to cut

Step 3: Tape Gatorshield to the floor on both sides using a 3" wide non-marking tape. Overlap the tape 1.5" onto the Gatorshield using the dotted line printed on the product. This will allow for 1.5" of tape to be applied to the flooring surface.

Step 4: If covering a wider floor space where more than one row of material is required. Overlap the side edges of the Gatorshield 1.5" over the tape used to secure the first row of product to the floor. Tape the overlap again with 3" tape using the solid line located 3" in from the edge of the Gatorshield to align the outer edge of the tape. Since tape is to product only non-marking tape is not required for the seams, any strong adhesive tape (housewrap or vapor barrier tape) will work.

Step 5: Tape the outside of the next row to the floor with non-marking tape. Repeat above procedure for additional rows.