

Thank you for choosing the rechargeable
Restorator DUO® by Vaportek
The dual-powered tool for all-around
odor control!

**PLEASE FOLLOW THESE INSTRUCTIONS FOR
INITIAL USE OF YOUR RESTORATOR DUO**

! **The Restorator DUO**
battery pack has been shipped in a
low-charge condition and must be
charged AT LEAST SIX HOURS
before initial use. **!**

Follow these instructions for charging the Ni-MH
battery pack provided with the Restorator DUO:

1. Insert battery pack, label side down into the compartment. Plug battery pack cord into the receptacle. Replace battery compartment cover and snap forward into place.
2. Plug battery charger into 120V, 60 Hz, AC electrical outlet. Connect charger to the Restorator DUO by inserting charger plug into the input jack at back of the unit. For initial charge, leave machine plugged in for at least six hours. Subsequent charges may need 3-6 hours for the battery pack to be fully charged.
3. The charge indicator light (LED) located at the top of the unit, under the handle, will remain green when ready to use. The light will flash green when charging is in progress; blinking red or no light indicates recharging is required.
4. The Restorator DUO will continue to charge when plugged into a 120V power supply with the switch in either the "On" or "Off" position. When battery pack is fully charged, unit will operate for approximately 18+ hours before recharging is required.
5. See Operation Instructions or www.vaportek.com for additional information about use.

LED INDICATOR

SOLID GREEN: *Ready to use*
BLINKING GREEN: *Charging*
BLINKING RED: *Recharging required*
NO LIGHT: *Recharging required*



Sussex, WI 53089
800.237.6367 | info@vaportek.com
www.vaportek.com

Thank you for choosing the rechargeable
Restorator DUO® by Vaportek
The dual-powered tool for all-around
odor control!

**PLEASE FOLLOW THESE INSTRUCTIONS FOR
INITIAL USE OF YOUR RESTORATOR DUO**

! **The Restorator DUO**
battery pack has been shipped in a
low-charge condition and must be
charged AT LEAST SIX HOURS
before initial use. **!**

Follow these instructions for charging the Ni-MH
battery pack provided with the Restorator DUO:

1. Insert battery pack, label side down into the compartment. Plug battery pack cord into the receptacle. Replace battery compartment cover and snap forward into place.
2. Plug battery charger into 120V, 60 Hz, AC electrical outlet. Connect charger to the Restorator DUO by inserting charger plug into the input jack at back of the unit. For initial charge, leave machine plugged in for at least six hours. Subsequent charges may need 3-6 hours for the battery pack to be fully charged.
3. The charge indicator light (LED) located at the top of the unit, under the handle, will remain green when ready to use. The light will flash green when charging is in progress; blinking red or no light indicates recharging is required.
4. The Restorator DUO will continue to charge when plugged into a 120V power supply with the switch in either the "On" or "Off" position. When battery pack is fully charged, unit will operate for approximately 18+ hours before recharging is required.
5. See Operation Instructions or www.vaportek.com for additional information about use.

LED INDICATOR

SOLID GREEN: *Ready to use*
BLINKING GREEN: *Charging*
BLINKING RED: *Recharging required*
NO LIGHT: *Recharging required*



Sussex, WI 53089
800.237.6367 | info@vaportek.com
www.vaportek.com